



# RicoRock 9 Inch Tile/Coping

Installation techniques for fiberglass pools

Silicone type adhesives have worked well for many installers. Rough up pool surface with sandpaper, clean and put silicone on both the pool beam and coping. It is best to add color and cut pieces if needed before setting.



Foam should be used to fill voids, some can be applied before install. Cement mortar should be used and finished after drying out, avoid smearing fresh mortar.

Most installers prefer to set coping before concrete is poured. Coping can be protected from concrete spills with duct tape or by applying dish soap to the rock and washing it off later. Cut pieces work on a radius but the individual coping pieces can also be cut for a cleaner look.

